

Eddie Bauer® Highpoint Fleece Jacket

PRODUCT MEASUREMENTS

	XS	S	М	L	XL	2XL	3XL	4XL
Chest	19	20.5	22	23.5	25	26.5	28.5	30.5
Body Length	27.25	28.25	29.325	30.5	31.625	32.75	33.325	34
Sleeve Length	34.75	25.5	36.25	37	37.75	38.5	39.25	40

CHEST WIDTH

BODY LENGTH AT BACK

Measured across the chest one inch below armhole when laid flat.

Measured from high point shoulder to finished hem at back.

SLEEVE LENGTH

Start at center of neck and measure down shoulder, down sleeve to hem.

SIZE CHART

_		XS	S	М	L	XL	2XL	3XL	4XL
ſ	Chest	32-34	35-37	38-40	41-43	44-46	47-50	51-54	55-57

CHEST WIDTH

Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal.